

Buried Services

To facilitate this ambition of getting the quality right, these checks should take place:

- Keep a photographic record of new services
- Ensure marker tape is installed to aid the identification / location of new services throughout the site
- It is recommended that tape incorporating a trace wire is used to aid future service location
- Test thoroughly prior to backfilling
- Dimensioned AS BUILT drawings of all installations required
- Avoid joints where possible in below ground services
- Check requirements for thrust blocks on fire hydrant and high pressure water mains
- Use local knowledge where possible
- Keep a photographic and written record of new services
- Ensure correct marker tape is installed to aid the identification / location of new services throughout the site

Our Quality vision:

We will get it right first time on all our projects by delivering exceptional customer service

